

Centennial Park and Pine Point Arenas

Switch between scoreboard and clock: VI, 99, #

Set period time: TIME, xxxx, #

Set period: PERIOD, x, #

Start or Stop time: STOP/GO

Increase score (# once per goal added): VS or HS, #

Set score (setting score to 00 will clear): VS or HS, xx, #

Set penalty (setting penalty to 0000 will clear): VP or HP, x, #, xxxx, #

(to make penalty changes, select the slot displayed on the board)

Horn: HORN, 0, #

x = your number, Press * to clear your number and re-enter it

