

OPERATOR'S INSTRUCTIONS – BARRETT EAST RINK

IMPORTANT, LOOK AT SCREEN WHILE PROGRAMMING, NOT WALL CLOCK!

*****NOTE YOUR ENTRY MUST BE DONE QUICKLY OR IT WILL TIME OUT*****

DISPLAY SCREEN

HOME SCORE	VISITOR SCORE	2:00	GAME TIME	INT MODE	7	8	9	HORN
HOME PNLTY	VISITOR PNLTY	5:00	TIMER UP/DOWN	PERIOD	4	5	6	
		10:00			1	2	3	RUN STOP
	RENTAL TIME	20:00			CLEAR	0	ENTER	

TO SET TIME CLOCK

1. PRESS "GAME TIME"
2. ENTER "CLR, CLR, CLR" TO CLEAR OLD ENTRY
3. PRESS "ENTER"
3. ENTER TIME YOU NEED AS 02 OR 15 OR 20
4. PRESS "ENTER"

TO SET PERIOD

1. PRESS "PERIOD"
2. ENTER PERIOD NUMBER "1" OR "2"
3. PRESS "ENTER"

TO SET GOALS

1. PRESS "HOME" OR "VISTOR SCORE"
2. PRESS "+1" AFTER EACH GOAL SCORED

TO SET PENALTY

1. PRESS "HOME OR VISITOR PENALTY"
2. ENTER "1 OR 2 OR 3" FOR FIRST SECOND OR THIRD PENALTY
3. PRESS "2:00" MINUTE BUTTON OR ENTER DESIRED TIME AND THEN ENTER.

TO CLEAR PENALTY

1. PRESS "HOME OR VISITOR PENALTY"
2. PRESS "CLR, CLR, CLR" TILL SCREEN CLEARED
3. PRESS "GAME TIME"

TO CLEAR GOALS

1. PRESS "HOME OR VISITOR SCORE"
2. PRESS "CLEAR"