

OPERATOR'S INSTRUCTIONS – BARRETT EAST SHOT CLOCK

HORN	MISC SHOT TIME	MISC MODES	SET
TIME OUT TIMER	PNLTY ON OFF	PNLTY INSERT	TIME
HOME GOAL	HOME SHOTS	PNLTY CLEAR	HOME PNLTY
GUEST GOAL	GUEST SHOTS	PNLTY EDIT	GUEST PNLTY

7	8	9	YES
4	5	6	NO
3	2	1	HOME SCORE
:	BLANK	0	GUEST SCORE

REMOTE CONTROLS should be connected to RIGHT side of NEVCO shot clock control box.

TO TURN CLOCK ON

1. ENTER MODEL NUMBER
2700100
2. SHOT CLOCK "YES"
3. ENTER "30"