

**OPERATOR'S INSTRUCTIONS – POTVIN ARENA (with REMOTE)**

**IMPORTANT, LOOK AT SCREEN WHILE PROGRAMMING, NOT WALL CLOCK!**

**\*\*\*NOTE YOUR ENTRY MUST BE DONE QUICKLY OR IT WILL TIME OUT\*\*\***

DISPLAY SCREEN

HOME SCORE	VISITOR SCORE	2:00	GAME TIME	INT MODE	7	8	9	HORN
HOME PNLTY	VISITOR PNLTY	5:00	TIME UP/DOWN	PERIOD	4	5	6	
HOME SHOTS	VISITOR SHOTS	10:00	PLAY TIMER SET	SHIFT	1	2	3	RUN STOP
+ 1	TEAM NAME	20:00	PLAY TIMER RESET	XXXXX	CLEAR	0	ENTER	

**TO SET TIME CLOCK**

1. PRESS "GAME TIME"
  2. PRESS "CLR, CLR, CLR" TO CLEAR OLD ENTRY
  3. ENTER TIME YOU NEED AS 2 OR 15 OR 20
  4. PRESS "ENTER"
- \*NOTE, TIMER MUST

**TO SET PERIOD**

1. PRESS "PERIOD"
2. ENTER PERIOD NUMBER "1" OR "2"
3. PRESS "ENTER"

**TO SET GOALS**

1. PRESS "HOME" OR "VISITOR SCORE"
2. PRESS "+1" AFTER EACH GOAL SCORED

**TO SET SHOT CLOCK**

1. PRESS "PLAY TIMER SET"
2. ENTER "30" THEN PRESS "ENTER"
3. PRESS "PLAY TIMER RESET" which will display 30 seconds on the shot clocks.
4. Press "GAME TIME" to return to game screen.
5. Reset using the new corded REMOTE

**TO SET PENALTY**

1. PRESS "HOME OR VISITOR PENALTY"
2. PRESS "1 OR 2 OR 3" FOR FIRST SECOND OR THIRD PENALTY & PRESS "ENTER".
3. PRESS "2:00" MINUTE BUTTON OR ENTER DESIRED TIME AND THEN "ENTER".

**TO CLEAR PENALTY**

1. PRESS "HOME OR VISITOR PENALTY"
2. PRESS "CLR, CLR, CLR" TILL SCREEN CLEARED
3. PRESS "GAME TIME"

**TO CLEAR GOALS**

1. PRESS "HOME OR VISITOR SCORE"
2. PRESS "CLEAR"

**TO QUIT SHOT CLOCK**

1. PRESS "PLAY TIMER SET"
2. PRESS CLEAR TWICE
3. PRESS "PLAY TIMER RESET"
4. PRESS "GAME TIME" AND YOU ARE IN NORMAL GAME MODE.