

SHOT CLOCK INSTRUCTIONS - ORC (MANLEY - WEST RINK)

NEVCO
CLOCK

Set UP - See instructions below for the following (ONLY IF THE SHOT CLOCK IS REQUIRED)
 - Turn Clock On (Ensure Shot Clock (SCS) & Time On/Off (TCS) Remotes are plugged into the side of unit if required - either side is OK)
 - Set Clock Time (to 99 minutes as black OES model will control time)
 - Set Period (to 1 but not really used, as this is shot clock only)

www.nevco.com

Model Code 871

tel: 800-461-8550

Alternative Time Control	Horn	Misc. Shot Time		Set	Time Out Timer				
					Start	Clear	Options	Yes	Confirm
		Penalty Insert	Penalty Edit	Time	7	8	9	No	Cancel
	Penalty On Off	Penalty Clear			4	5	6	Chronometer (Time of day)	
	Time On	Home Goal	Home Penalty	Home Shots	1	2	3	Home Score	
	Time Off	Guest Goal	Guest Penalty	Guest Shots		Blank	0	Guest Score	

TURN CLOCK ON

1. Turn Power button ON (Bottom, right hand side of unit) See note 1 below.
2. Press "NO" when asked to start where you left off last
3. Enter Model Number "871"
4. Press "YES" for shot clock. (This clock is not needed if no shot clock is required for game) See note 2 and 3 below.
5. At OB time, enter 30 then "YES"
6. At Penalty Time Out, enter "NO"

SET CLOCK TIME

1. Press "SET"
2. Press "TIME"
3. Enter "99" minutes to avoid conflicting with Black OES model (this clock is just for shot clock, black OES model will control time, goals and penalties).
4. Press "YES"

SET PERIOD

1. Enter "1" or "2", then "YES" (the black OES model will control the periods)

- Note 1:** The black OES unit controls the game time, periods, goals and penalties. This clock is only required if shot clock is required. If shot clock is required, you need to set this clock up to run it (almost like Senecal clock but with 99 minutes). You will need to stop and start the time on this clock to stop the shot clock also. Similar to Senecal clock.
- Note 2:** If "Bookmark" question instead of SHOT CLOCK, then you do not have the SC remote plugged into side of unit. The time ON/OFF remote is similar to Shot Clock remote, but they are not interchangeable. Time can be run off unit.
- Note 3:** If one of the shot clock's does not light up and display the time, switch the cables in behind the grey clock unit. It works for both one way, but not the other. You might have to turn off unit and redo the SET UP above to make it work OK.