

Score Clock Operating and Instructions:

1. Put the clock in game mode using the **GAME MODE** key. Press and hold the **CLEAR** key until hear a beep (about 5 seconds), this will clear any previous programs and data.
2. Enter Period by pressing the **PERIOD** key.
3. Enter the game time by pressing
 - a. **ENTER** key
 - b. Time required (15 min warm up, 20 minute period length)
 - c. Press the **CLOCKSET** key
4. To start the time, press the **RUN** key
5. To stop the time press the **STOP** key
6. To enter scores;
Select which team scores (home or visitors) and press the corresponding **SCORE** key. If you make a mistake and need to change the score then:
 - a. Press **ENTER** key
 - b. Input the desired number
 - c. Press the corresponding teams **SCORE** key
7. To record shot on goal
Select the team that saved the shot and press the corresponding **SHOT ON GOAL** key. Mistakes are corrected the same as correcting scores.
8. Penalties can be track up to 5 penalties per team at a time (indicated 1-5 on the control board display). As penalties end the other automatically shift to the correct order.

To enter a penalty:

- a. Press the **ENTER** key
- b. Press the "2" key (for a 2:00 minute penalty)
- c. Press the corresponding (home or guest) **PENALTY** key

To enter a second penalty:

- a. Press the corresponding (home or guest) **PENALTY** key (control panel will switch to show PEN 2 with 0:00 time)
- b. Press the **ENTER** key
- c. Press the "2" key (for a 2:00 minute penalty)
- d. Press the corresponding (home or guest) **PENALTY** key again

Enter all other penalties in the same manor if more occur (up to 5 at a time)

Canceling a Penalty

- a. Press the corresponding (home or guest) key until the **penalty** you want comes up on the control panel display screen.
- b. Press the **ENTER** key
- c. Press the "0" key
- d. Press the corresponding (home or guest) **PENALTY** key

Clock instructions KNRRRC

Make sure it's game ready by pushing GAMEMODE

Hold down CLEAR for 5 secs

Push ENTER
Input TIME - 13:00
Push CLOCK SET

Push RUN when puck drops
Push STOP to stop the clock

Push PERIOD to change the period

Score:

press ENTER
(Input the correct score ie 3)
Press SCORE

Make sure you are putting up on the right team. Each side has a button

Penalties:

Press ENTER
input 2:00
Press PENALTY for the right team

Clear penalty

Press ENTER
input 0
Press PENALTY for the right team

Putting up 2nd penalty

Press PENALTY for the right team
Press ENTER
input 2:00
Press PENALTY for the right team

Clearing penalty when there are 2:

Press PENALTY for the right team
Press ENTER
input 0
Press PENALTY for the right team
(May have to do repeat twice for penalty to actually clear)

Drop the clock

Push ENTER
Input TIME - 2:00
Push CLOCK SET

When you mess up score

Push ENTER
Input correct info (ie 4 goals)
Push SCORE for the right team

INTERVAL TIME

PUSH ENTER

INPUT TIME 1:30 (OR TIME
+ PERIOD)

PUSH INTERV. HORN!

*IT WILL BLIZZ FOR

5 SECS WHEN

POINTS PLACED!

Interval Horn.

Push Interval Horn

Push 1

Push enter

1:30 (enter interval time)

Push Interval Horn

Push Run when game begins

It's easy!

U9 Games

1. Hold down clear for 5 seconds → push game mode
2. Push enter
3. Enter 24:00
4. Push clock set
5. Push interval horn
6. Push 1
7. Push enter
8. Push 1:30
9. Push interval horn
10. Push run when game begins

*Make sure you push the ":" button or it won't work

Bluetooth Connected Sound System

Connect to DN-200BR to use Bluetooth for the Arena Sound System.

Push and hold 5 secs the Pair button on Bluetooth controller to pair your Device. In device setting, go to Bluetooth and pair/connect DN-200BR.

Pair button will also disconnect any connected devices. Unplugging power will also reset the Bluetooth Device.

Please do not adjust the volume on mixer or Bluetooth Device.

You can still connect with standard AV 3.5mm cable into the Mixer input.

