




## Player Penalty


Display	Action
 <p>HOME PLYR/PEN 1 PNN PN MM:SS</p> <p>NN = player number MM:SS = minutes, seconds</p>	<p>Press <b>&lt;PLAYER PENALTY •&gt;</b> to add a new penalty or edit an existing penalty for the home or guest team.</p> <p>To edit an existing penalty, use the up and down arrow keys to select the desired penalty, and then press <b>&lt;ENTER&gt;</b>.</p> <p>Enter the jersey number of the player with the penalty using the number pad, and then press <b>&lt;ENTER&gt;</b>.</p> <p>Press <b>&lt;CLEAR&gt;</b> twice to cancel and return to the game.</p>
	<p>The default penalty time initially displayed is the minor penalty value as defined in the <b>Settings</b>.</p> <p>Enter the penalty time by pressing the <b>&lt;MINOR PENALTY&gt;</b> or <b>&lt;MAJOR PENALTY&gt;</b> keys, or use the number pad to enter the correct penalty time, and then press <b>&lt;ENTER&gt;</b>. Pressing <b>&lt;MINOR PENALTY&gt;</b> or <b>&lt;MAJOR PENALTY&gt;</b> additional times will add the configured time for that penalty with each press.</p> <p><b>Note:</b> Press <b>&lt;CLEAR&gt;</b> if <b>&lt;MINOR PENALTY&gt;</b> or <b>&lt;MAJOR PENALTY&gt;</b> have been pressed too many times.</p>

## Set Main Clock

Display	Action
 <p>MAIN CLOCK -SET CURR MM:SS:T *</p> <p>MM:SS.T = minutes, seconds, tenths of a second</p>	<p>After the main clock has been stopped, press <b>&lt;SET MAIN CLOCK&gt;</b> to display the current time of the main clock.</p> <p>To change the time, enter the desired time using the number pad, and then press <b>&lt;ENTER&gt;</b>.</p> <p>Press <b>&lt;CLEAR&gt;</b> twice to cancel and return to the game.</p>
 <p>ADJUST PENALTY TIMERS Y/N?</p>	<p>This message appears if there are penalty times and <b>&lt;START&gt;</b> has been pressed at least once after setting the period time.</p> <p>Press <b>&lt;YES&gt;</b> to adjust all penalty timers to the correct time based on the time entered for the main clock, or press <b>&lt;NO&gt;</b> to not change the penalty timers.</p>


## Clear All Penalties

Press **<CLEAR ALL PENALTIES •>** to delete all of the penalties for the home or guest team.

Display	Action
 <p>HOME PLYR/PEN CLEAR ALL Y/N?</p>	<p>Press <b>&lt;YES&gt;</b> to clear the penalties for all players in the roster.</p> <p>Press <b>&lt;NO&gt;</b> to cancel and return to the game.</p>

## Delete Penalty

Press **<DELETE PENALTY •>** to delete a single penalty for the home or guest team.

Display	Action
 <p>HOME DEL PEN? 1 PNN PN MM:SS</p> <p>NN = current setting MM:SS = minutes, seconds</p>	<p>Use the up and down arrow keys to select the correct penalty, and then press <b>&lt;ENTER&gt;</b>.</p> <p>Press <b>&lt;CLEAR&gt;</b> to cancel and return to the game.</p>