

Merivale Arena – Clock Instructions

To start a new game:

- 1) Press **NEW GAME** then press **CLEAR**.
- 2) The clock will ask for timer direction, press **1** for down.
- 3) Asks you to enter period press **1** then **ENTER**
- 4) Enter period length, press **ENTER** again.

To add score:

- 1) Press **HOME OR GUEST SCORE** and it will increment 1 automatically
- 2) To edit score press **RECALL**, then home or guest score, then edit with keypad.

To start new period:

- 1) Press **PERIOD**
- 2) Enter period number and press **ENTER**, then enter period length.

Penalties:

- 1) To add penalty, press **HOME OR GUEST PENALTY**.
- 2) Press **ENTER**, then enter player number, press **ENTER**, and then the length of time, press **ENTER TWICE FOR A STOP TIME GAME**.
- 3) To edit penalty press **RECALL** then **HOME OR GUEST PENALTY** then edit time as needed.
- 4) To clear penalty press **RECALL** then **HOME OR GUEST PENALTY** then **CLEAR**.

Buzzer sounds automatically and will stop automatically after 5 seconds or so.