



Time Clock Instructions (Pason)

Getting Started

To ensure that the clock is reset to all its defaults, turn it off using the rocker switch on the right side of the console. Wait a few seconds, and then turn it back on. On the LED screen, you will be asked whether you want to start from where you turned off last. Enter [NO]. You will then be asked to enter the model number [871]. Finally, you will be asked if you want to use penalty time out, Enter [NO].

Setting the Time and Period

[SET] [TIME] [MMSS] [YES] [ENTER PERIOD NUMBER] [YES]

Note: enter the time as two-digit minutes, two-digit seconds and one digit 1/10's. Example: 15000 for 15 minutes.

Starting and Stopping the Clock

Use the hand held rocker switch to start and stop the clock. Be careful, as a small round button on the hand-held will sound the buzzer.

Entering a Goal

[HOME SCORE] OR [GUEST SCORE] [1] [YES]

To correct the score: [SET] [HOME SCORE] OR [GUEST SCORE] THEN [SCORE#]

Entering a Penalty

[SET] [HOME PENALTY] OR [GUEST PENALTY] [MMSS] [YES] [TWO DIGIT PLAYER NUMBER]

Example: if player is #7 then enter 07


Clearing a Penalty

[HOME PENALTY] OR [GUEST PENALTY] THEN [PENALTY CLEAR]


Note: pressing the [HOME PENALTY] OR [GUEST PENALTY] will cycle through the penalties until you reach the right one.


QUICK START GUIDE

With the scoreboard on and the control on the main time screen you are ready to set the time for the first period of play.



You are now ready for the game to begin.

To Start the Clock
Press  or use hand-held switch

To Stop the Clock
Press  or use hand-held switch


To Silence Auto Horn
Press 

Score
Press  or 

To Add To Goal Shots
Press  or 

Goal Saves
Press  or 

Then press a number key to add to the total value

To Set Period
Press 

Then press a number key to set the value