# SCOREBOARD INSTRUCTIONS FORUM (BOUCTOUCHE)







**MODEL CODE** 

8663274

# SET TIME/PERIOD



## START TIME / HORN

- Start / stop time using the switch at the top of the remote.
- Horn sounds off automatically at the end of period <u>TURN OFF</u> the time with the remote to turn off the horn.
- To sound the horn manually (hold a few seconds)


## **SET SCORE**



### **ADD SCORE**







#### CLEAR PENATLY



for 2nd penalty - use Home 2 PNLTY or Guest 2 PNLTY

