

## **CLOCK SET-UP INSTRUCTIONS**

- Main switch is on the right side
- After it is turned on, the display will read "Do you want to start where last left off?" Answer NO.
- Enter 0083261
- Display -- Question -- "NO"
- Display -- Question -- "NO"

### **TO SET MAIN TIME**

- SET → TIME → 1 → 0 → : → YES → 1 (or 2 or 3 period)

### **TO SET SCORE**

- SET → HOME SCORE (or GUEST) → 0

### **TO GET BACK TO MAIN TIME**

- TIME

### **TO ADD TO SCORE**

- HOME SCORE → 1 (will keep adding one)

### **TO SET PENALTIES**

- SET → HOME PENALTY (or GUEST) → 2 → : → YES → 9 → 9 (must enter 2 digits for player's number)

### **TO ERASE PENALTIES**

- HOME PENALTY (or GUEST) → PENALTY CLEAR → YES
- NOTE: If it is the second penalty you wish to clear, hit HOME PENALTY again to display that penalty