

Instructions

Guidelines:

- ◇ Rep: 3 minute warm up/Bunny: 5 minute warm up
- ◇ Stop time. Bunny auto-horn at 2 minute intervals.
- ◇ Rep: Do not display spread greater than 7 goals/Bunny: Do not display score
- ◇ Follow the prompts on the clock display.

Step 1. SOUND HORN (Call Teams to Ice)

Press **MANUAL HORN**

Step 2. PERIOD 1 SET UP

REP		BUNNY (Auto Horn)	
Action Key	Comments	Action Key	Comments
Press NEW GAME		Press NEW GAME	
Press C		Press C	
Press 1 for DOWN	timer direction	Press 0 for UP or 1 for DOWN	timer direction
Press #	period #1	Press #	period #1
Type 15	minutes	Type 14	minutes
Press #		Press #	
Press #	READY	Press #	
Press TIMER RUN	clock start	Press AUTO HORN	
Press TIMER HOLD	clock stop	Type 120	seconds
		Press #	READY
		Press TIMER RUN	clock start
		Press TIMER HOLD	clock stop

Step 3. PERIOD 2,3 ETC SET UP

Press PERIOD	
Type 2	period #
Press #	
Type 15	minutes
Press #	
Press #	READY
Press TIMER RUN	clock start
Press TIMER HOLD	clock stop

Step 3. PERIOD 2 SET UP

Press PERIOD	
Type 2	period #
Press #	
Type 14	minutes
Press #	
Press #	READY
Press TIMER RUN	clock start
Press TIMER HOLD	clock stop

Step 4. GOALS

Enter	Cancel a goal (posted to the wrong team)
Press SCORE HOME or GUEST	Press D Recall
Score Board ADDS 1	Press SCORE HOME or GUEST
	Enter Correct score
	Press #

Step 5. PENALTIES			
Enter		Cancel (Team Scores)	
Press PENALTY HOME	or	GUEST	Press RECALL
Press #		H-Player Number 00	Press PENALTY HOME or GUEST
Press #		H-Penalty Time	Press ADV or BACK (if nec) select pen. to cancel
Type 2 or 4 or 6 etc		minutes	Press C clear
Press #			Press #
Press #			

Note: Recommended to enter player number to help in tracking multiple penalties

Note: The 3rd or greater penalty will be held automatically and start running when it becomes the second remaining penalty.

Note: Some penalties are fully served. When cancelling a penalty, select the right one to cancel.

Restoring times to correct errors			
			Cancel Penalty Times
			Press RECALL
			Press PENALTY HOME or GUEST
			Press ADV or BACK (if nec) select pen. to cancel
			Press C clear
			Press #
			Re-Enter Penalties
			Press PENALTY HOME or GUEST
			Press # Player Number 00
			Enter Player number
			Press # Penalty time - mins
			Enter 0 or 1 etc
			Press # Penalty time - secs
			Enter number of seconds
			Press #