



Shawnigan Lake Arena- Time Clock

Please follow step by step instructions on how to run the score clock.

1) TURN ON CLOCK

- A. Press the BIG red button (*attached to the clock machine*)
- B. On the top left hand side of the clock machine, switch button from the off to on

2) CLOCK MODE

- A. Three options will appear. This will allow you to choose what sport you want to use the clock for. PRESS 3=H (*H is for Hockey*)

3) TIME

- A. Press the black "TIME" button and enter the amount of time for the period. To erase or fix, press the "TIME" button again and then correct time (*You can see everything on the console in front of you*)

4) STOP/START

- A. Press the green "*" button on the bottom left of the keypad.

5) PERIODS

- A. Press the red "#" button on the bottom right of the keypad. The periods go up to 4 and then start back at 1. If you make a mistake, keep pressing the button until corrected.

6) PENALTY

- A. Press "PLYR" then add the jersey number and amount of time serving.
Example "PLYR" 04-2:00 (*player 4 serving 2 minute penalty*)
- B. To erase a penalty (if a goal is scored for the other team), press "PLYR" add the number again and then 0:00.
Example "PLYR" 04-0:00 (*this will take the penalty off the board*)

7) GOALS

- A. Press white **HOME** button and red **GUEST** button.
- B. If you add too many goals by mistake, press and hold the same button and the numbers will count backwards.

OTHER IMPORTANT THINGS TO NOTE

- The right side of the machine is for the away team, and the left side is for the home team.
- The clock **MUST** be stopped to make adjustments.

